

# **Pump Up the Excitement with Pro Stage Mortars**

The CSL confetti launchers are the perfect fun and excitement DJ tool for any event.

Instructions:

**First:** Insert the lifting cup all the way into the canon via a rod (this is the double sided cardboard item).

**Second:** Load the confetti/streamers of your choice. If loading aerostreamers, allow a 6" tale at the end of the each streamer. For QuickLoad streamers simply drop in barrel.

**Third:** Cap the barrel, then use two bands of masking tape around the cap and barrel. This is very important to ensure the proper back pressure for more distance.

Hand or Pro Mortar screw the CO2 cartridge into the firing control assembly; be sure the level is in the down position before inserting the cartridge. Pull level fast - when ready.


Canons can be loud on discharge - use discretion on notifying the proper individuals before firing.

**1" Barrels** with streamers require no lifting cups - load with streamers and tape the end

**Pro 2" Stage Mortar** mount the canon and aim it in the direction you wish the payload to go! Run the tubing to the desired firing area (DJ booth).

Do not pinch the air cord or place it by a hot heater. Pull level fast when ready!

**Air Canon** version uses refillable air from any regular air compressor tank. Fill the air canon to 100 lbs pressure (the value is rated at 150lbs. - the Canon will lost 10 lbs per 12 hr. period adjust your air pressure according) Air Canons uses a remote self powered controller. Standard speaker cord can be used for the interconnect. **Important: On high pressure air tanks fill the Air Canon first before filling with confetti, Air tanks with 145 lb capacity can surge the valve to pre-release air and fire!**



Tripod mounting of Air Canon should be horizontal as shown  
Never aim at individuals or objects



## **Disclaimer: MISUSE CAN BE DANGEROUS!!**

Read all DIRECTIONS carefully before use. Products offered are for Professional Use Only! The manufacturer is not responsible for any injury or liabilities after purchase relating to use or misuse of any items received.

**PRODUCTS NOT OFFERED FOR SALE TO MINORS. YOU MUST BE 18 YEARS OR OLDER!**

Photo from:  
Creative DJ's

